

moogerfooger BOARD AC

|   |
|---|
| <b>SWITCHBLADE SLAVE</b>  |
| Digitech GSP1101-FEND   |
| <b>CHANDLER DELAY B</b>   |
| TRAY1   |
| MUTRON A-B  |
| TRAY2   |
| PLUSH PUREGAIN 1<br>PLUSH PUREGAIN 2<br>PLUSH CREAM<br>PLUSH DRIVER<br>BB PREAMP<br>TUBE DRIVER 1 |
| VOODOO  |
| TRAY3   |
| SYSTEC<br>TUBE DRIVER 2   |
| TRAY4   |
| GLOW VIBE<br>AFRO FUZZ<br>OCTAVIA<br>BOSS NS-2  |
| VOODOO  |
| BRADSHAW 2X5 and FEEDTHRU   |
| <b>FZ FX CAGE</b>   |
| <b>POWER</b>  |

|                           |                 |           |
|---------------------------|-----------------|-----------|
| <b>SWITCHBLADE MASTER</b> |                 |           |
| Digitech GSP1101 L        |                 |           |
| Digitech GSP1101 R        |                 |           |
| <b>DBX COMPRESSOR</b>     |                 |           |
| Eventide 949 HARMONIZER   |                 |           |
| <b>DYNAFLANGER 1</b>      |                 |           |
| <b>DYANFLANGER 2</b>      |                 |           |
| <b>ADA TIME FX</b>        |                 |           |
| <b>CHANDLER DELAY A</b>   |                 |           |
| <b>APHEX EXPRESSOR 1</b>  |                 |           |
| <b>APHEX EXPRESSOR 2</b>  |                 |           |
| <b>DECIMATOR</b>          |                 |           |
| FUELTANK                  | GIZMO4          |           |
| INWARD                    | GIZMO 3         |           |
| GIZMO 1                   | GIZMO 2         |           |
| HUMM ELIM                 | <b>FEEDTHRU</b> | HUMM ELIM |
| <b>BRADSHAW SUPPLY</b>    |                 |           |
| BLANK                     |                 |           |
| <b>POWER</b>              |                 |           |

FRONT VIEW ELEVATION